

## Megapack soft 2024 - volum I - 754 Gb - Stick aprilie 2024

Aproximativ 55 link-uri de 14Gb ~ 18Gb fiecare

**Reducere pentru cei care au luat ambele stick-uri din 2023 - 1001 si 1002**

Un pachet de softuri pe stick - **195 lei trimis prin curier**

REDUCERE = Ptr cei care au luat stick-urile 1001 + 1002 = **160 lei trimis prin curier**

Fara stick cu plata in cont si trimis pe mail , se scad 20 + 15 lei = **160 lei**

REDUCERE = Ptr cei care au luat stick-urile 1001 + 1002 = **125 lei** - Fara stick cu plata in cont si trimis pe mail

Abonatii le pot lua impreuna cu revista care apare pe 1 aprilie

- cu stick = **175 lei adaugati la ramburs**
- fara stick pe mail = **160 lei adaugati la ramburs**

REDUCERE Ptr abonatii care au luat stick-urile 1001 + 1002 si vor acest pachet de softuri impreuna cu revista

- cu stick impreuna cu revista = **140 lei adaugati la ramburs la revista**
- fara stick pe mail = **125 lei adaugati la ramburs la revista**

80% din cei care au luat 1001 au luat si 1002 deci vor beneficia de reducere daca vor si acest prim volum de softuri din 2024

**Cei care vor luat acest pachet de softuri vor beneficia de update gratuit la sfarsit de an cu tot ce adun nou la categoriile se afla in acest pachet - emmc-uri Sony , Panasonic , Hisense , softuri USB la sasiurile de aici , NVM , Flash , Nand - Sony , Panasonic - Monitoare - pinout eMMC**

Megapack soft 2024 - Volum I = CHINA - USB - VOLUM 1

1.345 fisiere - softuri pentru update pe USB ( nu flash )

Part 1

CV110-A32\	CV110-AL\	CV181H-A\	CV181H-X\	CV181L-A\	CV181L-Y\	CV182H-E\
CV182H-F\	CV182H-J\	CV182H-X\	CV182L_B\	CV182L-C\	CV306H-A-11\	
CV308H-A-10\	CV308H-I\	CV308H-J\	CV308L-K\	CV338H-A\	CV338H-A32\	CV338H-A42\
CV338H-A50\	CV338H-B32\	CV338H-B42\	CV338H-C42\	CV338H-D42\	CV338H-Q50\	
CV338HR-D32\	CV338H-T42\	CV338H-T50\	CV338H-U42\	CV53A-A32\	CV53A-A42\	
CV56BH-Q28\	CV56BH-Q42\	CV56BL-L\	CV56BL-Q24\	CV56XH-U28\	CV56XH-U32\	CV56XH-U42\
CV56XL-U24\	CV59H-BPW\	CV59L-C\	CV59L-G\	CV59L-K23\	CV59SH-A32\	CV59SH-C\
CV59SH-E32\	CV59SH-I42\	CV59SH-J\	CV59SH-U32\	CV59SH-U39\	CV59TH-B\	

Part 2

CV338H-U50\	CV351-B55\	CV351M-B42\	CV358H-A50\	CV358H-B42\	CV358H-T42\	CV358H-U32\
CV358-K32\	CV358L-T24\	CV512H-A\	CV512H-A50\	CV512H-B42\	CV512H-H42\	CV512H-Q42\
CV512H-U50\	CV512L-B\	CV512L-B24\	CV512L-Q24\	CV512L-U24\	CV538H-A\	CV538H-Q50\
CV551H-A50\						

Part 3

CV560-A55\	CV628H-A\	CV628H-A50\	CV628H-B42\	CV628H-T42\	CV638H-A42\	CV638H-B\
CV638H-B50\	CV638H-D\	CV638H-D50\	CV638H-E42	3MS638AU\	CV638H-E50\	CV648H-D\
CV719H\	CV801H-B\	CV828H-A\	CV828H-C\	CV828H-D\		

Part 4

CV920-E32\	CV920-E42\	CV920-E55\	CV920-F32\	CV920-F42\	CV920H-T42\	CV920H-U32\
------------	------------	------------	------------	------------	-------------	-------------

CV920H-U42\ CV950H-A32\ CV950H-A42\ CV950H-A50\ CV950XH-C42\ CV960H-A\ CV960H-A50\

Part 5

CV3393BL-C\ CV3463GL-X\ CV3553BH-Q32\ CV3663BL-B24\ CV3663BL-U\ CV3663C-A32\  
CV3663C-C42\ CV3683H-A42\ CV3683H-A50\ CV3686H-A50\ CV3686H-B\ CV3686H-B50\  
CV6308H-A42\ CV6308H-B42\ CV6308H-C\ CV6379H-A39\ CV6486H-B42\ CV6488H-S\  
CV6488H-Y\ CV6586H-A\ CV6586H-A50\ CV6681-B42\ CV6681H-A42\ CV6683H-C42\  
CV960XH-A50\ CV962D4-B55\ CV962H-A\

Part 6

CV6681-K42\ CV6886H-A\ CV9202H-B39\ CV9202H-CSM\ CV9202H-NPW\ CV9202H-T\  
CV9202H-TPW\ CV9202H-UPW\ CV9202L-T\ CV9203H-Q42\ CV9203L-A\  
CV9203L-Q24\ CV9256-A32\ CV9256-A42\ CV9256-A55\

Part 7

CV9632-B55\

Part 8

CV9632-K55\ CV9632-KH\ CV9632-L55\ CV9632-M42\ CVMV26L-A-20\  
CVMV26L-B-20\ CVMV29L-A\ CVMV29L-F\ CVMV39L-B\ CVX10H-A42\  
DKTV-B-EE-AG-20140610-M\ DP.6A358.813\ DP.V53RL.671\ DS.D3663LUA.A81.2.PA\  
DS.D3663LUA.A8-1-A\ DS.V53RL.BK\ E182VG-Z0-A0\ E182VG-Z1-B0\  
E309B-Y2-F0\ EV59XUS-Y1-A0\ GSD56UI3T0-V1.4D.1\  
GSD59IT0-V1.0\ GSDXLI3T0-V1.1\ GSL-V59XU-Z1\ GT.56J.01\



**Part 15**

HK.T.RT2871V09\  
MSOV591-ZC01-01\  
MS33930-ZC01-01\  
MS34637-ZC01-01\  
MS63082-ZC01-01\  
MSA3480-ZC01-01

HK.T.RT2957P65\  
MS308C0-ZC01-01\  
MS34630-ZC01-01\  
MS36631-ZC01-01\  
MS63083-ZC01-01\  
MSA3481-ZC01-01

MPLE31N75 REV1.2\  
MS308C1-ZC01-01\  
MS34631-ZC01-01\  
MS36632-ZC01-01\  
MS65860-ZC01-01\  
MSA3487-ZC01-01

MSOU691-ZC01-01\  
MS368V3.0\  
MS34633-ZC01-01\  
MS36633-ZC01-01\  
MS68860-ZC01-01

**Part 16**

**Part 17**

MSA3483-ZC01-01\  
MSA6284-ZC01-01\  
MSA6285-ZC01-01 - Part I\  
MSA6285-ZC01-01 - Part II

MSA3489-ZC01-01\  
MSA6380-ZC01-01

MSA6381-ZC01-01

MSA6381-ZC01-01

**Part 18**

MSA6284-ZC01-01\  
MSA6285-ZC01-01 - Part I

**Part 19**

MSA6285-ZC01-01 - Part I

**Part 20**

MSA6285-ZC01-01 - Part II

**Part 21**

MSA3485-ZC01-01

## Megapack soft 2024 - Volum I = EMMC PINOUT

Imagini cu punctele de conexiune pentru programare eMMC

1396 fisiere , probabil sunt si poze dubluri cu denumiri diferite

Contine la zi tot ce s-a publicat pe forumuri , tot ce s-a vandut la pachete , etc

## Megapack soft 2024 - Volum I = Sony - EMMC

60 softuri eMMC

### Part 1

BAXL 1-889-202-12 T550HVF05.1 TH58NVG3S0HTAIO EMMC Sony KDL-55W817B.rar

BB9 1-983-119-11 emmc toshiba easyjtag tv nou citit ok Sony KD-65XF7005 XF7005.rar

BB9 1-983-119-11 IC7501 THGBMDG5D1LBAIL EMMC Sony KD-65XF7096.rar

BB9 1-983-119-11 Sony KD-43XF7077 A-220-7525A EMMC.rar

BB9 1-983-119-12 easyjtag emmc toshiba ok Sony KD-49XG7005 XG7005.rar

BCH 1-982-627-11 Sony KD-65X8566F EMMC.rar

BCH 1-982-627-11 V550QWME07 EMMC Sony KD-55X8500F.rar

BCX2 1-982-626-21 T430HVF03.2 H26M52208FPR EMMC Sony KDL-43WF805.rar

### Part 2

BCN 1-002-850-31 YS9S049HNG01 EMMC Sony KD-43XH8005.rar

BCX 1-982-454-11 HV550QUBN5K EMMC Sony KD-55X7500F.rar

BCX 1-982-454-21 YM8S550CN001 KLMAG1JETD EMMC Sony KD-55XF7596.rar

BLM 1-981-541-21 emmc Toshiba read after reset ok Sony KDL-49WE660 WE660 WE755.rar

BLM 1-981-541-21 Sony GN3UN THGBMDG5D1LBAIL EMMC.rar

BLM 1-981-541-21 THGBMDG5D1LBAIL EMMC Sony GN3UN.rar

### Part 3

BFX 1-981-326-13 V550QWSE09 EMMC Sony KD-55XF8096.rar

BFX 1-981-326-33 H26M52208FPR EMMC Sony KD-49XF8096.rar

BKA 1-982-096-11 EMMC Sony KD-65A1.rar

BLM 1-981-541-13 NS7S490HN01 THGBMDG5D1LBAIL EMMC Sony KDL-49WE665.rar

Part 4

BFM 1-980-837-11 LC490EQY-SJA3 KLMAG1JENB-B041 EMMC Sony KD-49XD7005.rar

BCX2 1-982-626-11 LC430EQY-SLA1 KLMAG1JENB EMMC Sony KD-43XF7596.rar

BAXF 1-893-272-21 THGBMAG5A1JB AIR EMMC Sony KD-55X8505B.rar

715G8133-M0E-000-005K EMMC Sony KD-49X6000D.rar

Part 5

BFX 1-981-326-12 EMMC Sony KD-43XE8096.rar

BFX 1-981-326-12 emmc samsung ok Sony KD-55XE8096 XE8096.rar

BB8 1-981-926-21 V550QWSE05 THGBMOG5D1LBAIL EMMC Sony KD-55XE7096.rar

Part 6

BMFW 1-894-595-12 Sony KD-49X8305C EMMC.rar

BFX 1-981-326-12 EMMC SAMSUNG CITIT OK KD-55XE8096 XW8096 MAIN.rar

BFM 1-980-837-21 YS6550CNG01B EMMC 16G Sony KD-55X7000D.rar

BFM 1-980-837-21 SONY KD-55XD7005 dump eMMC.rar

Part 7

BMFL 1-894-596-21 emmc toshiba easyjtag 36mhz tv ok Sony KD-55X8509C X8509C X8xxx.rar

BM5 1-006-895-11 Sony KD-55X9000H EMMC.rar

BM3J19 1-984-326-11 EMMC Sony KD-65X9500G.rar

BM1 1-980-833-11 - citit Sony FW-85XD9501 -.rar

Part 8

BM5ST 1-010-115-31 YDBM075DCS02 KLMBG2JETO EMMC Sony XR-75X90J.rar

Part 9

BMFW 1-894-595-12 doar o panglica display testat ok Sony KD-49X8005 x8005.rar

BMFW 1-894-595-11 KLMAG2GEND-B031 EMMC Sony KD-55X8000C.rar

BMFL 1-894-596-22 Sony KD-55X8509C H26M52103FMR EMMC.rar

BMFL 1-894-596-22 H26M52103FMR easyjtag 24mhz testat ok Sony KD-55X8509C X8509C X8505.rar

Part 10

BMFW 1-894-595-12 X8005 EMMC\_ROM1\_HAG2e\_495599834\_00000000\_400000000 testat ok Sony 49'.rar

BMFW 1-894-595-12 testat pe KD-65S8505C ok SONY KD55S8505C S8505C.rar

BMFW 1-894-595-12 Sony KD-49X8005C GN1T EMMC.rar

BMFW 1-894-595-12 Sony KD-43X8309C x8000 x8309 citit.rar

Part 11

BPE 1-982-629-11 EMMC Sony KDL-43WF665.rar

BMFW2 1-980-832-11 V650QWM02 EMMC Sony KD-65X8500D.rar

BFM 1-980-837-11 V550QWSE01 EMMC Sony KD-55XD8005.rar

Part 12

BMKP 1-982-021-11 eMMC SONY KD-65XE9305.rar

BMKP 1-982-021-11 EMMC Sony KD-65X9300E.rar

BFX 1-981-326-32 V550QWSE10 EMMC Sony KD-55X8000E MT555832.rar

Part 13

BMKS 1-982-022-31 KLMAG1JENB-B041 EMMC Sony KD-49XE9005.rar

BMKS 1-982-022-21 EMMC Sony KD-65X8500E.rar

BMKS 1-982-022-11 IC2001 KLMAG1JENB-B041 testat ok Sony KD-55XE8596 XE8596.rar

Part 14

BMX2 1-980-805-31 H26M52103FMR MT5830BPHJ citit tv ok, testat ok Sony KDL-43W756C w755 w7xx.rar

BMX2 1-980-805-31 H26M52103FMR EMMC Sony KDL-50W805C.rar

BMX 1-893-880-11 1-893-880-21 Sony KDL-65W850C EMMC.rar

Part 15

BSL 1-983-791-22 MT5833 V550QWME09-1JETD EMMC Sony KD-55X8500G.rar

BNB 1-003-740-11 EMMC Sony KD-85X8000H.rar

Part 16

BSL 1-983-791-12 Sony KD-55XG8596.rar

BMFW2 1-980-832-21 Sony KD-55X8500D.rar

BMFW 1-894-595-12 citit emmc ok kd49x8309c x8000 x8305c x8505c s8505c.rar

BMFL 1-894-596-22 Sony. Kd-556X8509c eMMC DUMP .rar

Megapack soft 2024 - Volum I = Sony - NVM FLASH VCT NAND

323 softuri

Nand - FLASH - NVM

Sony\_KDL-40W2000-IC3206\_HYNIX-HY27US08281A\_FEE nand\

Sony\_WAX2\_HY27US08281\_FEE\_Nand.rar

Sony\_KDL-50W656A\_RB1G\_T500HVF03.0\_Nand\_TC58NVG3SOFTA.rar

Sony\_KDL-46EX402\_AZ1-N\_3A-2\_SPI\_Nand\_Flash\_M25P10\_HY27UF081G2M.rar

Sony\_KDL-42EX440\_AZ3FK\_P-2LT\_Nand\_H27U518S2C.rar

Sony\_KDL-40W605B\_RB2G-HM\_1-889-202-22\_Nand\_Flash.rar

Sony\_KDL-40W2000-IC3206\_Nand\_HYNIX-HY27US08281A\_FEE\_Board.zip

Sony\_KDL-40S5600\_Nand\_Flash\_NAND512W3A.rar

Sony\_KDL-40S5600\_Nand\_Flash.zip

Sony\_KDL-40S5600\_EX2N\_LTY400HA12\_Nand\_NAND512W3A.rar

Sony\_KDL-40S2510\_WAX2\_Nand\_Flash\_FEE.rar

Sony\_KDL-40R480B\_ITC3\_Nand\_TC58NVG1S3HTAIO.rar

Sony\_KDL-37S5600\_EX2N\_T370HW02 V.B\_Nand.rar

Sony\_KDL-37P3000\_SE2\_1-874-223-11\_Nand.rar

Sony\_KDL-32S5600\_Nand\_SPI\_NVM.rar  
Sony\_KDL-32S5600\_Nand\_NAND513WCNA3.rar  
Sony\_KDL-32S5600\_Nand\_Flash\_NVM.rar  
Sony\_KDL-32S5600\_EX-2N Peppermint\_AVC\_LTY320HA03 A02\_NAND512W3A2CN6F.rar  
Sony\_KDL-32S5600 Nand.rar  
Sony\_KDL-32S2000\_FE\_1-869-656-21\_Nand\_Flash.rar  
Sony\_KDL-32EX600\_AZ1-L\_5-2P\_Nand\_Flash.rar  
Sony\_KDL-32EX600\_A-1767-672-A\_LTY320HM02\_Nand\_IC4704\_HY27UF081G2M.rar  
Sony\_KDL-32EX402\_AZ1N\_LTY320HM01 A02\_Nand\_H27U1G8F2BTR.rar  
Sony\_KDL-26P3020K\_A1276-477-A\_Nand\_NAND128W3A.rar  
Sony\_KDL-26L4000\_Nand\_Flash\_NVM.rar  
SONY\_1-881-019-13\_NAND.rar  
SONY\_1-876-638-11\_NAND FLASH HY27US08281A.rar  
Sony KLV-40R452A A1944359C 0141095V1 TC58DVM92A5TA00 NAND.rar  
Sony KLV-40NX500 A1782710A LTY400HM01 24C02 24C128 NAND512W3A.rar  
Sony KLV-40EX500 1-880-238-21 NAND.rar  
Sony KLV-32R402A 1-888-352-12 TC58DVM92A5TA00 NAND.rar  
Sony KLV-26BX310 A1825501A0853899R1 T260XW05 V.0 K9F1208UOCPIB0.rar  
Sony KLV-22BX300 1-880-238-33 T216XW01-V3 IC9600 K9F1208UOC NAND.rar  
Sony KDL-55W805A 1-888-101-41 LC550EUF TC58NVG3SOFTA00 NAND.rar  
Sony KDL-55W800B 1-889-202-22 T550HVF05 TH58NVG3SOHTA00 NAND.rar  
Sony KDL-50W800B 1-889-202-22 T500HVF04.0 MT29F8G08A.rar  
Sony KDL-50W685A 1-888-390-11 T500HVJ02.0 TC58DVG3SOETA00 NAND.rar  
Sony KDL-50W656A RB1G T500HVF03.0 TC58NVG3SOFTA NAND.rar  
Sony KDL-47W807A 1-888-101-31 LC470EUF TC58NVG3SOFTAIO NAND.rar  
Sony KDL-46X2000 1-871-615-12 S29JL032H70TFI01 NAND.rar

Sony KDL-46R473A 1P-012CJ01-4010 S460DH1-1 U4004 TC58DVM92A5TA00.rar  
Sony KDL-46EX402.rar  
Sony KDL-42W808A 1-888-101-31 LC420EUF-FFP2 TC58NVG3SOFTA00 NAND.rar  
Sony KDL-42W705B 1-889-202-22 T420HVF06 TC58NVG3SOFTA00 NAND.rar  
Sony KDL-42EX443 1P-0125J00-4011 R4225Q37N10 24C128 HY27US08121A NAND.rar  
SONY KDL-42EX440 ZY100110A 1P-0125J00-4011 nand din tv defect.rar  
SONY KDL-42EX440 ZY100110A 1P-0125J00-4011 nand.rar  
Sony KDL-42EX440 V420HK1-XRS5 H27U518S2C NAND.rar  
Sony KDL-42EX410 SOLED\_32\_MT66\_EU\_IP\_MB S0103-1 LC420EUN (SD)(V4) HY27US08121B NAND.rar  
SONY KDL-42EX410 SOLED\_32\_MT66\_EU\_IP\_MB S0103-1.rar  
Sony KDL-40X2000 1-871-615-12 HY27US08281AT.rar  
Sony KDL-40WD653 1-980-335-32 TC58NVG2SOHBIAI4 NAND.rar  
Sony KDL-40W605B 1-889-202-22 NAND.rar  
Sony KDL-40W5500 1-878-942-22 LTY400HF05 K9F1208U0C NAND.rar  
Sony KDL-40W2000 IC3206 HYNIX-HY27US08281A NAND.rar  
Sony KDL-40V5500 1-878-942-12 LTZ400HA07 Nand + NVM.rar  
Sony KDL-40V3000 1-874-734-11 T400HW01-V1 IC3002 M24256 IC7200 HY27US08281A NAND.rar  
SONY KDL-40U2000 1-870-688-13 SE-1.rar  
Sony KDL-40R483B 1-889-355-12 TC58NVG1S3HTA00 NAND.rar  
Sony KDL-40R480B 1-889-355-13 NAND + NVM.rar  
Sony KDL-40R473A, RB1FK, FY13\_EU 1P-012CJ01-4010 Y200A540A NAND.rar  
Sony KDL-40R471A 1P-012CJ01-4010 TC58DVM92A1FT00 S400DH1-3 TC58DVM92A1FT00 NAND.rar  
Sony KDL-40R470A 1P-012CJ01-4010 U4004 TC58DVM92A1FT00 NAND.rar  
Sony KDL-40R453B 1-889-355-13 TC58NVG1S3HTAIO NAND.rar  
Sony KDL-40R450B 1-889-355-12 LSY400HM03-A02 TC58NVG1S3HTA00 NAND.rar  
Sony KDL-40R380D 715G8321-M01-000-004K TPT400LA.rar

Sony KDL-40P2530 1-872-686-11 A-1242-773-A LTA400WT-L05 HY27US08281A.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 IC4704 H27U1G8F2BTR NAND.rar  
Sony KDL-40EX401 1-881-019-13 LTY400HM01 M25P10 H27U1G8F2BTR NAND.rar  
SONY KDL40D3500 be1f 1-875-865-11 lty400ha1 hy27us08281a.rar  
Sony KDL-40D3500 1-875-865-11 HY27US08281A.rar  
Sony KDL-40BX450 MT5367-MB-PAD LTA400HM19 IC4600 TC58DVM92A5TA10.rar  
Sony KDL-37V5500 1-878-942-12 T370HW02-V.B 24C32 K9F1208UOC NAND NVM.rar  
Sony KDL-37U4000 1-876-638-11 T370XW02-V.C NAND.rar  
Sony KDL-37S5650 A-1641-831-A 25P10VP 24C64 512W3A2CN6 NAND Flash NVM.rar  
SONY KDL-37S5600\_1-878-999-22\_NAND512W3A@TSOP48.rar  
Sony KDL-37S5600 EX2N 1-878-999-21 T370HW02-V.B IC4701 NAND512W3A NAND.rar  
Sony KDL-37P3600 1-878-999-11 24C64 M25P10-AV NAND512W3A.rar  
Sony KDL-37P3000 SE2 1-874-223-11 1-874-223-12 T370XW02.rar  
Sony KDL-37EX401 1-881-019-13 IC4704 H27U1G8F2BTR IC4104 M25P10.rar  
Sony KDL-32W706B 1-889-202-22 TC58NVG3SOFTA00 NAND.rar  
Sony KDL-32W705C w705c w805 w807 w828 w815 1-894-336-31 citit tv ok.rar  
Sony KDL-32W653A 1-980-335-32 TC58NVG2SOHBIAI4 NAND.rar  
Sony kdl32w4210 LTY320HA02\_eeprom&nand.rar  
Sony KDL-32V4500 1-875-656-22 24C32 24C32 K9F5608UOD NAND.rar  
Sony KDL-32V2500 1-869-656-21 LTZ320WS-LH3 C3206 HY27US08281A IC4003 24C256 IC4009 .rar  
Sony KDL-32U3000 1-874-223-12 LTA320WT-L06 24C32 NAND NVM.rar  
Sony KDL-32T2600 1-873-891-13 T315XW02-VE NAND128W3A2BN.rar  
Sony KDL-32S5600 Nand Flash NVM.rar  
Sony KDL-32S5600 EX-2N Peppermint 1-878-999-11 LTY320HA03-A02.rar  
Sony KDL-32S3020 1-873-891-12 T315XW02 NAND128W3A.rar  
Sony KDL-32S3000 1-873-891-23 T315XW02 NAND NVM.rar

Sony KDL-32S2530 WAX2 S2000 S2500 S2530.rar  
Sony KDL-32S2530 1-869-656-21 HY27US08281A.rar  
Sony KDL-32S2030 1-869-656-21 LTY320WS-L05 IC3206 HY27US08281A NAND.rar  
Sony KDL-32S2020 1-869-656-12 1-869-852-12 LTY320WS-L05 HY27USD8281A NAND.rar  
Sony KDL-32S2010 1-869-852-21 24C256 29AL016D70TFI01 HY27US08281A NAND.rar  
Sony KDL-32s2000 Wax2.rar  
SONY KDL-32S2000 Chassis (Main Board) CI MODUL\_HY27US08281A.rar  
Sony KDL-32S2000 1-869-850-15 HY27US08281 NAND.rar  
Sony KDL-32R435B A2048993C 0056430Q1 TC58NVG1S3HTAIO NAND.rar  
Sony KDL-32R433B 1-889-355-12 TC58NVG1S3HTAIO NAND.rar  
Sony KDL-32R425A 715G5678-M01-000-004K TPT315B5 U405 TC58NVG1S3ETAIO NAND.rar  
Sony KDL-32R400A 1P-012CJ00-4012 S320DB3-1.rar  
Sony KDL-32R330D 715G8321 TPT315B5-WHBN0.K.rar  
Sony KDL-32R303B 1-893-413-11 NAND.rar  
Sony KDL-32P3550 EX2N-Peppermint 1-878-999-12 NAND.rar  
Sony KDL-32P3020 1-874-223-12 LTA320WT-L06 24C32 NAND NVM.rar  
Sony KDL-32EX600 A-1767-672-A LTY320HM02 IC4704 HY27UF081G2M NAND IC4104 M25P10-A.rar  
Sony KDL-32EX402 AZ1-N 1-881-019-52 LTY320HM01-A02.rar  
Sony KDL-32EX301 1-881-019-32 LTY320AP05 24C64 M25P10 H27U1G8F2B.rar  
Sony KDL-32D3000 1-873-000-11 LTZ320WH-LH2 HY27US08281A S29AL016M90TFI01 24C256.rar  
Sony KDL-32D2600 1-873-891-13 T315XW02.rar  
Sony KDL-32BX420 1-895-018-21 T315HW04 H27U518S2CTR.rar  
Sony KDL-32BX400 1-881-019-62 Nand.BIN  
Sony KDL-32BX340 MT5367 S1101-1 48.73R01.011 LTA320AN08 TC58DVM92A5TAIO NAND.rar  
SONY KDL-32BX340 KDL-40BX440 MT5367\_MB S1101-1 48.73R01.011 Nand restart Logo.rar  
Sony KDL-26S2020 1-869-850-12 S29AL016D70TFI01 24C256 HY27US08281A NAND NVM.rar

Sony KDL-26S2010 1-869-850-15 HY27US08281A NAND.rar  
Sony KDL-26S2000 1-869-656-21 HY27US08281A NAND.rar  
SONY KDL-26P3020K.zip  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U31 NAND512W3A.rar  
Sony KDL-26B4030 1-874-223-12 V260B1-L07 Rev.C3 IC7200 NAND128W3A2BN6 IC4003 24C32.rar  
Sony KDL-22EX302 1-881-019-32 T216XW01-V.3 H27U1G8F2BTR NAND.rar  
Sony KDL-20S2020 1-870-688-11 V201B1-L01 IC5680 HY27US08281A NAND.rar  
Sony KD-43XG8396 1-982-627-12.rar  
Sony KD-40R470A 1P-012CJ01-4010 S400DH1-3 TC58DVM92A5TAJO NAND.rar  
SONY \_1-870-688-13\_NAND HY27US08281A.rar  
BLE 1-888-390-11 citit tv ok Sony KDL-42W650A W650A.rar

NVM - Flash - VCT

NVM

Sony\_KV-SP29M89K\_BX1L\_24C32.zip  
Sony\_KLV-40V200\_IC1005\_M24256B.rar  
Sony\_KLV-32S550A\_A-1707-715-A\_V315B3-L01\_IC3002\_24C128.rar  
Sony\_KLV-32NX400\_AZ1-A\_24C128.rar  
Sony\_KDL-55EX720\_AZ2F\_24C02WP.zip  
Sony\_KDL-40Z4500\_LTY400HG01.rar  
Sony\_KDL-40W4500\_EG1L\_ST24C64WP.rar  
Sony\_KDL-40EX500\_LTY400HF06\_Y2008710J\_24C32WP.rar  
SONY\_KDL-37V4000\_SE2AG\_1-876-638-11\_T370XW02.rar  
Sony\_KDL-37P3000\_SE2\_1-874-223-11\_24C32.rar  
Sony\_KDL-32W5800\_1-878-942-41\_24C32WP.rar  
Sony\_KDL-32R420A\_RB1FK\_24C128.rar  
Sony\_KDL-32P3000\_24C02.RAR

Sony\_KDL-32BX320\_24C128.rar  
Sony\_KDL-26P5550\_24C64.rar  
SONY\_KDL-26B4050\_24C32W.rar  
Sony KLV-V40A10E A-1086-128-E 1-867-499-15 LTA400WS-L04 24C16.rar  
Sony KLV-B15G10 E213371 94V-0 TX34D11VCOF-AA 24LC16BI.rar  
Sony KLV-40Z550A A-1728-475-A LTY400HG02.rar  
Sony KLV-40W400A 1-876-534-11 24C256.rar  
Sony KLV-40V200 IC1005 M24256B.rar  
Sony KLV-40EX500 1-880-238-33 IC7004 24C32 IC9200 24C128.rar  
Sony KLV-40BX401 1-880-238-32 T400HW03-V.0 IC9200 24C128.rar  
Sony KLV-40BX400 A-1782-698-A LTY400HM01 IC9200 24C128.rar  
Sony KLV-32R306C 32R306 24C64.rar  
Sony KLV-32R300A 715G5819-M01-000-004K TPT315B 24C64.rar  
Sony KLV-32NX500 1-880-238-33 24C128.rar  
Sony KLV-32NX400 1-880-238-21 LTY320AP5 001 24C128.rar  
Sony KLV-32EX330 1-887-041-32 SLS320NN01 IC8003 24C128.rar  
Sony KLV-32CX320 MT66-PA-S0102-2 24C128.rar  
Sony KLV-32BX301\_1-880-238-21\_LTY320AP04\_IC9200\_24C128.rar  
Sony KLV-32BX300 1-880-238-32 LTY320AP04 IC9200 24C128.rar  
Sony KLV-26U300A BD 2970063605-A V260B1-L07 Rev.C3 24C64.rar  
Sony KLV-26NX400 1-880-238-32 V260B3-L05 Rev.C1 24C128.rar  
Sony KLV-22BX301 1-880-238-33 T216XW01 V.3 24C128.rar  
Sony KDL-47W808A 1-888-101-31 TPS65178A.rar  
Sony KDL-46V5500 1-878-942-12 LTY460HB11 24C32.rar  
Sony KDL-46EX715 1-881-636-22 T460HW04 24C32W.rar  
Sony KDL-46EX700 1-881-636-11 LTY460HJ02 24C32.rar

Sony KDL-42EX440 EX440 1P-0125J00-4011.rar  
Sony KDL-40Z4500 1-877-366-13 LTY400HG01.rar  
Sony KDL-40WE5 A-1663-964-B LTY400HF02 24C32.rar  
Sony KDL-40W4500 1-877-366-13 LTY400HC02-001 ST24C64WP.rar  
Sony KDL-40W4000 1-875-656-12 A-1363-835-A 24C32.rar  
Sony KDL-40S5650 A-1641-831-A 24C64.rar  
Sony KDL-40S4000 1-877-114-12 LTY400HA11 24C32.rar  
Sony KDL-40S2000 1-869-850-12 LTZ400WS-L02 24C256.rar  
Sony KDL-40R474A 1-888-121-11 S400DH1-3 U4003 24C128.rar  
Sony KDL-40NX710 1-882-799-11 LTK400HF01 24C32.rar  
Sony KDL-40NX705 1-881-779-12 LK400D3LA4T M24C32-WP.rar  
Sony KDL-40NX700 1-881-779-11 LK460D3LA8T 24C32.rar  
Sony KDL-40HX700 1-881-636-41 LTY400HM01 24C32.rar  
Sony KDL-40EX700 1-881-636-31 LK400D3LA4S 24C32.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 ICR2 24C02 EEPROM.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 ICE1 24C64 EEPROM.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 IC590 24C02 EEPROM.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 IC4101 24C64 EEPROM.rar  
Sony KDL-40EX500 1-881-636-22 LTY400HF06 24C32WP.rar  
Sony KDL-40EX40B 1-881-636-31 LTY400HM01 24C32.rar  
Sony KDL-40E4020 1-875-656-12 LTY400HA05 24C32WP.rar  
SONY KDL40D3500 be1f 1-875-865-11 lty400ha1 hy27us08281a eeprom.rar  
Sony KDL-40BX440 MT5367 S1101-1 48.73R01.011 LTA400HM19 24C128.rar  
Sony KDL-40BX420 MT5366JATG LTY400HM07 24C128.rar  
Sony KDL-40BX400 1-881-019-13 LTY400HM01 24C64.rar  
Sony KDL-37V5810 1-878-942-31 A-1701-876-A T370HW03 24C32.rar

Sony KDL-37V5610 1-878-942-12 T370HW02 24C32.rar  
Sony KDL-37V4500 1-875-656-22 T370XW02 24C32.rar  
Sony KDL-37V4000 SE2AG 1-876-638-11 T370XW02.rar  
Sony KDL-37U3000 1-874-223-11 T370XW02 V.5 IC4003 24C32.rar  
Sony KDL-37S4000 1-876-638-11 T370XW02 IC4104 24C32.rar  
Sony KDL-37P5500 1-878-999-21 24C64.rar  
Sony KDL-37EX500 1-88-636-22 T370HW03-V.9 24C32.rar  
Sony KDL-37BX420 MT66 EU S00100-2 V370H4-L01 24C128.rar  
Sony KDL-32W5800 1-878-942-41 24C32WP.rar  
Sony KDL-32W4000 1-875-656-12 24C32.rar  
Sony KDL-32V4000 1-876-638-11 LTZ320AA01 24C32.rar  
Sony KDL-32V2000 1-869-852-12 LTZ320WS-LH3 24C256.rar  
Sony KDL-32R430B 1-889-355-12 24C128.rar  
Sony KDL-32R424 1P-012CJ01-4010 S320DB3-1 24C128.rar  
Sony KDL-32R423A 1P-012CJ01-4010 S320DB3-1 U4003 24C128.rar  
Sony KDL-32R420A 1P-012CJ01-4010 24C128.rar  
Sony KDL-32R410B 1-889-355-13 IC5001 24C128.rar  
Sony KDL-32P3000 1-874-223-12 24C32W.rar  
Sony KDL-32L4000 1-857-143-11 LTY320AB01 24c64.rar  
Sony KDL-32EX710 1-881-636-41 T315HW07 24C32WP.rar  
Sony KDL-32EX707 1-881-636-22 LK315D3LA4S 24C32.rar  
Sony KDL-32EX605 1-881-636-11 LTY320HM02 24C32.rar  
Sony KDL-32EX40B 1-881-636-22 LTY320HM03 24C32WP.rar  
Sony KDL-32EX401 1-881-019-13 LTY320HM03-A03 24C64.rar  
Sony KDL-32EX343 1P-0125J00-4011 V320BJ3-XC01 24C128.rar  
Sony KDL-32EX340 1-895-285-11 V320BJ6-PE1 U4003 24C128.rar

Sony KDL-32E4050 1-875-656-12 LTY320HA02 24C32.rar  
Sony KDL-32CX521 1-883-753-32 V315H3-L01.rar  
Sony KDL-32BX320 1-895-018-11 T315XW03 24C128.rar  
Sony KDL-32BX310 A-1844-889-A T315XW04 24C128.rar  
Sony KDL-32BX300 1-881-019-32 LTY320AP05 IC4101 24C64.rar  
Sony KDL-26U4000 1-876-638-11 LTA260AP01 24C32.rar  
Sony KDL-26U3000 1-874-223-12 A-1276-477-A V260B1-L07 24C32.rar  
Sony KDL-26S2030 1-869-852-21 M42568.rar  
Sony KDL-26P3000 A-1276-477-A V260B1-L07 24C32.rar  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U46 24C04.rar  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U45 24C64.rar  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U42 24C02.rar  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U41 24C02.rar  
Sony KDL-26B4050 9-927-595-01 V260B1-L07 24C32.rar  
Sony KDL-20S3000 A-276-477-A T200XW02-V1 24C32.rar  
Sony GNS-500PA KR022TVL-V01 190ME13 24C08.rar

#### Flash VCT NVM

Sony\_KLV-32S550A\_A-1707-715-A\_V315B3-L01\_25Q080.rar  
Sony\_KLV-22S570A\_EX2T\_T216XW01.rar  
Sony\_KLV- 32S550A\_EX2T\_1-878-659-11\_LTY320AP03\_24C02\_25V080B.zip  
Sony\_KDL-40U2000\_LTA400WT-L05.rar  
Sony\_KDL-40NX720\_AZ2-F\_LSY400HF01.rar  
Sony\_KDL-32U2000\_SE1\_T315XW02 V.1\_24C32\_VCT6973G.rar  
Sony\_KDL-32S5600\_LTY320HA03\_25P10VP\_24C64WP.rar  
Sony\_KDL-32EX600\_A-1767-672-A\_LTY320HM02\_IC4104\_M25P10-A.rar  
Sony\_KDL-32EX600\_A-1767-672-A\_LTY320HM02.rar

Sony\_KDL-32EX402\_AZ1N\_LTY320HM01 A02\_IC4101\_R1EX24064ASAS0A\_25P10VP.rar  
Sony\_KDL-32EX401\_25P10VP.rar  
Sony\_KDL-32EX401\_1-881-019-13\_LTY320HM03 A03.rar  
Sony\_KDL-32D2810\_24C32\_VCT.rar  
Sony\_KDL-26U2000\_SE1\_LTA260W2-L19.rar  
Sony\_KDL-26P5550\_25P10.rar  
Sony\_KDL-26P3020K\_A1276-477-A\_24C32\_CXD9922R.rar  
Sony L44B MSD309B-T9B K420WL 25Q32B.rar  
Sony KLV-40V440A 1-876-534-13 1-876-534-11 LTY400HA10 S29AL032D70TFI03.rar  
Sony KLV-37S550A 1-878-659-11 T370XW02 NVM FLASH.rar  
Sony KLV-32V400 1-875-581-13 24C32 24C64 SST25VF080B T-CON 24LC128 SST24C64.rar  
Sony KLV-32T550A 1-878-659-22 LTY320AP02 NVM FLASH.rar  
Sony KLV-32S550A A-1707-715-A all panel\_NVM\_SPI.RAR  
Sony KLV-32S200A 1-870-445-11 NOR NVM.rar  
Sony KLV-32G480A 1-876-385-12 LTA320AP05 25L08.rar  
Sony KLV-32BX205 IP-009CJ00-4013 REV4.3 LTY320AP04.rar  
Sony KLV-30HR3 1-863-275-17 flash nvm.rar  
Sony KLV-26S550A 1-878-659-11 NVM FLASH.rar  
Sony KLV-26BX205 MST6M16C MX25L3205.rar  
Sony KLV-26BX205 1P-0107J00-4011 V260B2-L01.rar  
Sony KLV-24P422C 715G7371-MOC-000-004K MX25L12805D.rar  
Sony KLV-24P413D 1P-0156X07-4010 V236BG1-LE2 Rev.C1 25L1283SF.rar  
Sony KLV-24P412B 715G6552-MOD-000-004K MX25L12835F.rar  
Sony KLV-22S570A EX2T T216XW01 NVM FLASH.rar  
Sony KLV-22P402B 715G6552-MOD-000-004K.rar  
Sony KLV-15SR2 1-689-914-12 IC2002 24C16 IC1008 24C64 IC2010 M27W201 MX29LV800ATTC-70G.rar

Sony KDL-50W808C 1-893-880-11 V500FWME01 T550HVN08.2 flash nvm.rar  
Sony KDL-50W756C 1-893-880-11 V500FWME01 25L3206E.rar  
Sony KDL-46W2000 1-871-232-11 29LV160B.rar  
Sony KDL-46S2030 1-869-852-21 LTY460WS-L04 NVM FLASH.rar  
Sony KDL-46S2000 A-1179-060-D NOR NVM.rar  
Sony KDL-46HX820 1-883-754-12 LSY46HQ01 NVM FLASH.rar  
Sony KDL-43W808C 1-980-805-31 V430FWME03 flash nvm.rar  
Sony KDL-43W756C 1-893-880-11 V430FWME03 flash nvm.rar  
Sony KDL-43W755C 1-893-880-21 V430FWME01 flash nvm.rar  
Sony KDL-40ZX1 1-878-242-11.rar  
Sony KDL-40W2000 1-871-229-12 LTY400HS-LH3 29LV160.rar  
Sony KDL-40V4000 1-877-114-12 LTY400HA06 VCT NVM.rar  
Sony KDL-40U2530 1-872-686-11 LTA400WT-L05 VCT.rar  
Sony KDL-40U2520 1-872-686-11 A-1242-773-A LTA400WT-L05 NVM + VCT.rar  
Sony KDL-40U2000 1-870-688-13 LTA400WT-L05 NVM + VCT.rar  
Sony KDL-40S3000 1-873-891-13 LTZ400WT-LH3 NVM + VCT.rar  
Sony KDL-40S2510 1-871-991-21 LTY400WT 29LV160CT.rar  
Sony KDL-40EX720 1-883-753-93 LTY400HF09 flash nvm.rar  
Sony KDL-40EX600 1-884-019-32 LTY400HM02 IC4104 25P10 SPI.rar  
Sony KDL-40EX402 1-881-019-32 IC4104 M25P10A.rar  
Sony KDL-37P5600 1-878-999-21 T370HW02-V.B Flash + NVM.rar  
Sony KDL-37EX402 A-1767-672-A 1-881-019-32 IC4104 M25P10A.rar  
Sony KDL-32U2000 1-870-688-11 NVM + VCT.rar  
Sony KDL-32S5550 1-883-753-32 LK315T3LA3S flash nvm.rar  
Sony KDL-32S5500 FLX00018746-109 LTZ320AA03 25P10.rar  
Sony KDL-32S4000 1-876-638-11 LK315T3LA3S.rar

Sony KDL-32P5500 1-857-345 LTY320AP02 LTY320AP02007 Flash + NVM.rar  
Sony KDL-32L4000 1-857-143-11 LTY320AB01 M25P10VP.rar  
Sony KDL-32EX700 1-881-636-11 LK315D3LA4S Flash + NVM.rar  
Sony KDL-32EX6000 1-881-019-32 25P10.rar  
Sony KDL-32EX401 1-881-019-13 LTY320HM03-A03 IC4104 25P10VP SPI.rar  
Sony KDL-32EX302 1-881-019-32 LTY320AP04 flash nvm.rar  
Sony KDL-32BX400 A-1767-672-A 1-881-019-32 LTY320HM01 M25P10A.rar  
Sony KDL-32BX300 1-881-019-32 LTY320AP05 IC4104 M25P10.rar  
Sony KDL-26U2000 1-871-875-11 LTA260W2-L19 24C32 NVM + VCT.rar  
Sony KDL-26L4000 1-857-143-B LTA260AP01 U47 M25P10A.rar  
Sony KDL-20S2030 1-870-688-11 V201B1-L01 NVM + VCT.rar  
Sony KDL-20S2000 1-870-688-13 V201B1-L02 VCT.rar  
Sony KDL-20G2000 1-870-897-12 NVM + VCT.rar  
Sony KDL-19L4000 1-857-143-31 M190Z1-L01 Rev C1 M25P10.rar  
Sony KDL-15G2000 1-870-688-13 CLAA150XP07F NVM + VCT.rar  
Sony KD-65XD9305 1-980-833-11 YD6S650STN01.rar  
Sony KD-55XE8577 1-982-022-31 V550QWME04.rar  
Sony KD-55XD9305 1-980-833-11 25X40.rar  
Sony KD-49XF8596 1-982-627-21 YD8S490HND01.rar  
Sony KD-49XF8577 1-982-627-11 YD8S490HND01.rar  
Sony KD-49X8505B 1-893-272-21 LYV4931 FLASH NVM.rar  
Sony KD-49X8005C 1-894-595-12 LC490EQY-SHM2 IC5200 25X40.rar  
Sony KD-43XF8577 1-982-627-11 YD8S430HNG01.rar  
Sony KD-43X8309C 1-894-595-11 W25X40.rar  
Sony KD-43X8308C 1-894-595-12 IC5200 25Q32.rar  
Sony ETV103-21D LA.MV6.C4 0242 M185B3-LA1.rar

**Megapack soft 2024 - Volum I = Panasonic - EMMC**

**13 softuri eMMC**

TNPH1137 H26M31003GMR IC8920 Panasonic TX-65CZ950E OLED\  
TNPH1197 2A TXFZL55KHAA EMMC Panasonic TX-55FX700E.rar  
TNPH1181 V400HJ9MD1 KLM4G1FEPD EMMC Panasonic TX-40ES403E.rar  
TNPH1181 2A LC320DXE KLM4G1FEPD EMMC Panasonic TX-32FS400E.rar  
TNPH1179 1 A EMMC Panasonic TX-55EXW604.rar  
TNPH11601A L5EDDY00849 IC8920 THGBMBG5D1KBAIT EMMC Panasonic TX-55DXR600.rar  
TNPH1137 EMMC Panasonic TX-65CZ950E.rar  
TNPH1077 1A Panasonic TX-42ASE650 LC420DUF-VGF1 THGBM5G5A1 EMMC.rar  
TNPH1077 1A LC420DUF-VGF1 THGBM5G5A1 EMMC Panasonic TX-42ASE650.rar  
TNP4G633 V400HJ9-MD1 Rev.C2 EMMC Panasonic TX-40FSR500.rar  
TNP4G633 Panasonic TX-40FSR500 V400HJ9-MD1 Rev.C2 EMMC.rar

**Megapack soft 2024 - Volum I = Panasonic - FLASH NAND**

**364 softuri**

**Panasonic Original**

Panasonic TX-PR50UT30 TNPH0938A1.rar  
Panasonic-TX-32S400E TNPH1181 EB TXNA1MGWE LC320DXY(SH)(A4) eMMC.rar  
Panasonic\_VIERA\_TH-42PV7P\_NVM.RAR  
Panasonic\_TX-PR37C2\_TNPH0829\_Nand\_H27U1G8F2BTR.rar  
Panasonic\_TX-P50X20E.rar  
Panasonic\_TX-P46GW20\_GPF13DE.rar  
Panasonic\_TX-P42X20E\_GPH13DE\_MX25L1635D.rar

Panasonic\_TX-P42X10E\_TNPH0782 2A FE-TP3.rar  
Panasonic\_TX-P42X10E\_24C16.rar  
Panasonic\_TX-P42UT30.rar  
Panasonic\_TX-P42U20E\_24C16W.rar  
Panasonic\_TX-P42U20E\_24C16.rar  
Panasonic\_TX-P42U10E\_TNPH0784 BE-TP3 BE TXNA1EKUE\_MD42JF12PE1\_MC106F16T12.rar  
Panasonic\_TX-P42S30E\_TNPH0938 1A\_W25Q32B.rar  
Panasonic\_TX-LR32EM5A\_MT5367PAHU\_24C64.rar  
Panasonic\_TX-L42E5E\_TNPH0993[4]A\_LC420EUN (SE)(M3)\_24C64F.rar  
Panasonic\_TX-L42E5E\_TNPH0993[3]A\_LC420EUN\_24C64F.rar  
Panasonic\_TX-L39EM5E\_TNP4G535.rar  
Panasonic\_TX-L37E5E\_TNPH0993\_TXN-A10TLUB\_IC8902\_24C64F.rar  
Panasonic\_TX-L32X20E\_TNPOEA017 8A\_AX080A076E\_24C16\_24C32.zip  
Panasonic\_TX-L32E5E\_TNPH0992\_1A\_Nand\_Flash\_29F4G08ABADA.rar  
Panasonic\_TX-L32D25E\_TNPH0877\_Nand\_H27U1G8F2BF.rar  
Panasonic\_TX-L32D25E\_TNPH0877\_LC320EUH\_24C08\_24C64.rar  
Panasonic\_TX-L32C10P\_TNPOEA014\_VCT6973\_EDID HDMI\_24C32.rar  
Panasonic\_TX-L32C10P.rar  
Panasonic\_TX-L26X10E\_TNP8EA101.rar  
Panasonic\_TX-50A400B\_TNP4G566.rar  
Panasonic\_TX-48C320\_17MB97\_VES480UNESU-01.rar  
Panasonic\_TX-39AW404\_TNP4G566 A1\_V390HJ1-LE6 REV.F1\_MX25L12835F\_24C64.rar  
Panasonic\_TX-32LX80PA\_GLP23A\_24C32.rar  
Panasonic\_TX-32LX60P\_GLP21\_24C32.rar  
Panasonic\_TX-32E3E\_TNP8EA114\_VVX32F101G00\_Nand\_H27U1G8F2BTR.rar  
Panasonic\_TX-32AW304\_17MB95M\_VES315WNDL-N01\_MX25L1606E.rar

Panasonic\_TX-26LE60P\_GLP21\_24C32.rar  
Panasonic\_TX-20LA80F\_GLP21\_24C32.rar  
Panasonic\_TH-L39B6M\_TNP4G542\_W25Q64.rar  
Panasonic\_TX-R37LX85\_TNP8EAL90\_AX094A011A\_24LC16BT.rar  
Panasonic\_TX-R32LX86K\_TNPH07292A\_AX080A015A.rar  
Panasonic\_TX-R32LX80KS\_TNP4G431\_LTA320AA03.rar  
Panasonic\_TX-R32LM70K\_TNPOEA009\_LTA320WT-L15.rar  
Panasonic\_TX-R32LE8S\_TNP4G431BP\_LTA320AA03.rar  
Panasonic\_TX-R32LE7KA\_TNPOEA009.rar  
Panasonic\_TX-R32LE7K\_TNPOEA009\_A9\_LTA320WT-L15\_24C32.rar  
Panasonic\_TX-R26LE8KS\_TNP4G4313A\_V260B1-L12\_REV.C1\_IC1102\_24C128.rar  
Panasonic\_TX-R26LE7K\_TNPOEA009\_LTA260W2-L12\_24C32AN.rar  
Panasonic\_TX-R20LA80\_TNPOEA008\_V201V1-T03\_Rev.C4.rar  
Panasonic\_TX-PR65VT60\_TNPH1044\_IC8900\_MT29F4G08ABAEA\_NAND.rar  
Panasonic\_TX-PR55ST50\_TNPH0989\_25Q16.rar  
Panasonic\_TX-PR50XT50\_TNPH0990\_YB28H2G9RK47.rar  
Panasonic\_TX-PR50VT20\_TNPH0844\_IC1101\_24C08.rar  
Panasonic\_TX-PR50UT50\_TNPH0991(2)A\_IC8902\_24C64F\_IC9304\_25Q16CV\_TC58NVG2S3ETA00\_NAND.rar  
Panasonic\_TX-PR50U30\_TNPH0954\_MD-50JF14NE2\_MX25L1605A.rar  
Panasonic\_TX-PR50U20\_TNPH0830\_1A\_24C16\_24C32\_25L1636D\_H27U1G8F2BTR.rar  
Panasonic\_TX-PR50ST30\_TNPH0936\_HY27UF082G2B\_IC9304\_NAND.rar  
Panasonic\_TX-PR50S10\_TNPH0784.rar  
Panasonic\_TX-PR50G10\_TNPH0784\_(1A)\_MC127F19T12.rar  
Panasonic\_TX-PR50C3\_TNPH0939.rar  
Panasonic\_TX-PR50C2\_TNPH0829\_MD-50LH13NE1.rar  
Panasonic\_TX-PR42UT50\_TNPH09912A\_W25P16.rar

Panasonic TX-PR42U30 TNPH0954.rar  
Panasonic TX-PR42U20 TNPH0830.rar  
Panasonic TX-PR42U10 TNPH0784 MC106F16T12.rar  
Panasonic TX-PR42ST50 TNPH0989 25Q40.rar  
Panasonic TX-PR42S20 TNPH0830 1A MD42JF13PE1.rar  
Panasonic TX-PR42GT20 TNPH0899 24C08 24C64 25L16 H27U1G8F2BT NAND.rar  
Panasonic TX-PR42C3 TNPH0939.rar  
Panasonic TX-PR42C21 TNPH0829 MD-42LH13PE1.rar  
Panasonic TX-PR42C2 TNPH0829 MD-42LH13PE1.rar  
Panasonic TX-PR42C11 TNPH0782.rar  
Panasonic TX-PR42C10 TNPH0782 MD-42LH12PE4 IC9303 S29AL016D.rar  
Panasonic TX-PR37C2 TNPH0829 H27U1G8F2BTR NAND.rar  
Panasonic TX-PR37C2 TNPH 0829 H27U1G8F2BTR NAND.rar  
Panasonic TX-PR37C10 TNPH0782 24C64.rar  
Panasonic TX-P50X60E TNPH1047 W25Q16.rar  
Panasonic TX-P50X5VE TNPH1002TXNA IC8900 H27U1G8F2BTR-BC NAND.rar  
Panasonic TX-P50X20E TNPH0829 2A MC127H36V13.rar  
Panasonic TX-P50X10Y TNPH0783.rar  
Panasonic TX-P50VT50E TNPH0988 1A.rar  
Panasonic TX-P50VT30E TNPH0935 24C64.rar  
Panasonic TX-P50VT20E TNPH0844(1)A IC1101.rar  
Panasonic TX-P50STW50 TNPH0989 25Q16 24C64 NAND.rar  
Panasonic TX-P50ST33E TNPH0936 IC9304 25Q32 HY27UF082G2B NAND.rar  
Panasonic TX-P50G30E TNPH0937 1A H27UF082G2B NAND.rar  
Panasonic TX-P50G20E TNPH0838 2A.rar  
Panasonic TX-P42X50E TNPH1002 1A W25Q16.rar

Panasonic TX-P42X20E TNPH0829AB MX25L1635D.rar  
Panasonic TX-P42UT30B TNPH0829.rar  
Panasonic TX-P42U30E TNPH0954 MD-42JF14PE2.rar  
Panasonic TX-P42U20E TNPH0830 MD42JF13PE1 24C16W HY27UF081G2A NAND.rar  
Panasonic TX-P42U10E TNPH0784 MD42JF12PE1 MC106F16T12.rar  
Panasonic TX-P42S30E TNPH0938 HY27UF08 NAND.rar  
Panasonic TX-P42GT20E TNPH0899 MD-42FF13PE2.rar  
Panasonic TX-P42G30E TNPH0937 1A IC8901 24C64WP IC8902 24C64WP IC8900 HY27UF082G2B NAND.rar  
Panasonic TX-P42C10E TNPH07822A MD42GH12ME1.rar  
Panasonic TX-P37X20E TNPH0829 2A.rar  
Panasonic TX-LR65WT600 TNPH1066 L5EDDY00538 MT29F4G08ABAEA NAND.rar  
Panasonic TX-LR50B6 TNP4G548 LC500DUE-SFR1 IC8900 MT29F1G08ABAEA NAND.rar  
Panasonic TX-LR47ET5 TNPH0993 1A LC470EUD-SEF2 IC8902 24C64 IC9350 M25P40-V IC8900 NAND.rar  
Panasonic TX-LR47DT60 LA42 TNPH1056 MT29F4G08ABAEAWP NAND.rar  
Panasonic TX-LR42U3 TNPOEA019 24C32WP.rar  
Panasonic TX-LR42U20 TNP4G468 1A M24C16WP M24C32WP H27U1G8F2BTR NAND.rar  
Panasonic TX-LR42ET5 TNPH0993 3A LC420EUN MT29F4G08ABADAWP NAND.rar  
Panasonic TX-LR42E5 TNPH0993 NAND.rar  
Panasonic TX-LR39EM5A TNP4G535 V390HJ1-LE2 REV.C1.rar  
Panasonic TX-LR32XM5A TNP4G535 T320XVN 01.1.rar  
Panasonic TX-LR32X5 TNP4G527A1.rar  
Panasonic TX-LR32X30 TNPH0849.rar  
Panasonic TX-LR32X3 TNP8EA119.rar  
Panasonic TX-LR32U3A TNP8EA117 VVX32F100G00.rar  
Panasonic TX-LR32U20 TNP4G468 1 A AX080F072G.rar  
Panasonic TX-LR32S10 TNP4G461 LC320WXN-SBC2.rar

Panasonic TX-LR32ET5W TNPH0993 4A LC320EUD-SEF1 IC8902 24C64.rar  
Panasonic TX-LR32EM5A TNP4G535 T320HVN0.1 24C64.rar  
Panasonic TX-LR32E6 TNPH1041 1A LC320EUN-FFM1 IC8900 H27U4G8F2DTR NAND.rar  
Panasonic TX-LR32E5 TNPH0992 2A 24C64 MT29F4G08ABADAWP NAND.rar  
Panasonic TX-LR32E3 TNP8EA114 9A VVX32F123G00.rar  
Panasonic TX-LR32C3 TNP8EA112 VVX32H100G00.rar  
Panasonic TX-LR32C20 TNP4G466 AX080A076G IC8004 24C16.rar  
Panasonic TX-LR32C10 TNP4G460 2A.rar  
Panasonic TX-LR32B6 TNP4G548 1A MT29F1G08ABAEAH NAND.rar  
Panasonic TX-LR22X20 TNP4G476 HY27UF081G2M NAND.rar  
Panasonic TX-LR19X10 TNP4G4601A LC320WXN-SBC2 24C16.rar  
Panasonic TX-LF42S20 TNP8EA106 LC420WUB-SCA1 IC1101 24C16 IC8950 24C32 H27U1G8F2BTR NAND.rar  
Panasonic TX-LF42E30 TNPH0931A1.rar  
Panasonic TX-L55ET5E TNPH0993 2A LC550EUD-SEF3 24C64.rar  
Panasonic TX-L50B6E TNP4G548 MT29F1G08ABAEA NAND.rar  
Panasonic TX-L47ETW50 TNPH0993 3A VVX42F129G00 IC8902 24C64.rar  
Panasonic TX-L47ETS51 TNPH0993 24C64WP.rar  
Panasonic TX-L47ET60E TNPH1038 LC470EUD IC8900 H27U4G8F20 NAND.rar  
Panasonic TX-L47ET5E TNPH0993 LC470EUD-SEF2 NAND.rar  
Panasonic TX-L47E5E TNPH0993 29F4G08AAC NAND.rar  
Panasonic TX-L47E5E TNPH0993 24C64.rar  
Panasonic TX-L47DT50E TNPH0993 4A VVX47F130B20 24C64.rar  
Panasonic TX-L42V20E TNPH0850.rar  
Panasonic TX-L42U3E TNPOEA0199A LC420WUN.rar  
Panasonic TX-L42U2E TNP8EA106 LC420WUN-SCD1 IC8950.rar  
Panasonic TX-L42S20E TNP8EA106 LC420WUB IC1101 24C16W IC8950 24C32W H27U1G8F2BTR NAND.rar

Panasonic TX-L42EW6 TNPH1041 1A H27U4G8F2ETR NAND.rar  
Panasonic TX-L42EW5 TNPH0993 LC420EUN 24C64 MT29F4G08ABADA NAND.rar  
Panasonic TX-L42ETX54 TNPH09934A LC420EUD.rar  
Panasonic TX-L42ETW5W TNPH0993(2)A 3 LC420EUD-SEF2 24C64.rar  
Panasonic TX-L42ETN53 TNPA5587 LC420EUD M25P40.rar  
Panasonic TX-L42ET60E TNPH1038-1A H27U4G8F2ETR NAND.rar  
Panasonic TX-L42ET5E\_TNPH0993\_TXN-A10UGUE\_SPI 24C64F IC8902\_LC420EUD(SE)(F2).7z  
Panasonic TX-L42ET5E\_TNPH0993\_TXN-A10UGUE\_NAND 29F4G08ABADA IC8900\_LC420EUD(SE)(F2).7z  
Panasonic TX-L42ET5E\_TNPH0993\_FR BOARD TNPA5587\_TXNFR1TLUB\_IC9350 M25P40.7z  
Panasonic TX-L42ET5E TNPH09933A L420EUD-SEF2 24C64 MT29F4G08ABADA NAND.rar  
Panasonic TX-L42ET5B TNPH0993A IC8902 24C64F.rar  
Panasonic TX-L42ET5B TNPH0993A IC8900 MT29F4G08ABADA NAND.rar  
Panasonic TX-L42ET50E TNPH0993 AT24C64.rar  
Panasonic TX-L42E6E TNPH1041 V420HJ1-LE6 H27U4G8F2DTR NAND.rar  
Panasonic TX-L42E6B TNPH1041 1A NAND.rar  
Panasonic TX-L42E6 TNPH1041 NAND.rar  
Panasonic TX-L42E5E TNPH0993 LC420EUN 29F4G08ABADA NAND.rar  
Panasonic TX-L42E5 TNPH0993 LC420EUN-SEM3 NAND 29F4G08AAC.rar  
Panasonic TX-L42E3E TNP8EA114 LC420EUN-SDV2 IC8901 24C16 IC8902 24C32HT27UF081G2M NAND.rar  
Panasonic TX-L42DTW60 TNPH1056 1A LC420EUD 24C64 29F4G08ABAEA NAND.rar  
Panasonic TX-L42DT60E TNPH1056 1A LC420EUD MT29F4G08ABADA 24C64.rar  
Panasonic TX-L42DT50E TNPH0993 2A VVX42F130B20 IC8900 29F4G08ABADA NAND.rar  
Panasonic TX-L42D25E TNPH0851 2A LC420EUH-SCA3.rar  
Panasonic TX-L39EM5E TNP4G535.rar  
Panasonic TX-L39E6E TNPH1041 V390HJ1-LE6 H27U4G8F2DTR NAND.rar  
Panasonic TX-L39B6E TNP4G548 1A T390HVN02.1 MT29F1G08ABAEAWP NAND.rar

Panasonic TX-L37U10E TNP8EA102 8A S29GL256N90TFIR2 NAND.rar  
Panasonic TX-L37ETX54 TNPH0993 3A U5 24C16.rar  
Panasonic TX-L37ETW5W TNPH0993 24C64F.rar  
Panasonic TX-L37ETW5 TNPH0993 A1 24C64 MT29F4G08ABADA NAND.rar  
Panasonic TX-L37ET5E TNPH0993 LC370EUD-SEF2 24C64.rar  
Panasonic TX-L37ET5E TNPA5587 CI 9350.bin  
Panasonic TX-L37E5E TNPH0993 TXNA10TLUB IC8902 24C64.rar  
Panasonic TX-L37E30E TNPH0931 VVX37F115G00.rar  
Panasonic TX-L37D25E TNPH0851 1A LC370EUH-SCA3.rar  
Panasonic TX-L32X5E TNP4G522 VVX32H125G00.rar  
Panasonic TX-L32X20E TNPOEA017 8A AX080A076E.rar  
Panasonic TX-L32X15P TNP8EA5 24C16.rar  
Panasonic TX-L32U2E TNP8EA106 IC8950 24C32.rar  
Panasonic TX-L32U10E TNP8EA102 8A AX080F044G.rar  
Panasonic TX-L32S20E TNP8EA106 H27U1G8F2BTR NAND.rar  
Panasonic TX-L32S20E TNP8EA106 AT24C32.rar  
Panasonic TX-L32S20E TNP8EA106 AT24C16.rar  
Panasonic TX-L32S10BA TNP8EA1028A AX080F044E 24C16.rar  
Panasonic TX-L32ET5EW TNPH0993A 3A LC320EUD MT29F4G08ABADA NAND.rar  
Panasonic TX-L32ET5EW TNPH0993A 3A LC320EUD 25P40.rar  
Panasonic TX-L32ET5EW TNPH0993A 3A LC320EUD 24C64.rar  
Panasonic TX-L32E5E TNPH0992 29F4G08ABADA NAND.rar  
Panasonic TX-L32D25E TNPH0877 LC320EUH H27U1G8F2BFB 2408 2464 NAND.rar  
Panasonic TX-L32C4E TNP4G510-A VVX32H121G00 24C16 24C32 H27U1G8F2BTR NAND.rar  
Panasonic TX-L32C2EA TNPOEA017 8A AX080A076G.rar  
Panasonic TX-L32C2E TNPOEA0178A AX080A076G 24C16 24C32 H27U1G8F2BTR.rar

Panasonic TX-L32C20LA TNPOEA017 8A H27U1G8F2BTR NAND.rar  
Panasonic TX-L32C20E TNPOEA017 8A AX080A076G IC1101 24C16 IC8950 24C32H27U1G8F2BTR NAND.rar  
Panasonic TX-L32C10P TNPOEA014.rar  
Panasonic TX-L32BL6E TNPH1041A H27U4G8F2ETR NAND.rar  
Panasonic TX-L32B6E TNP4G548 MT29F1G08ABAEA NAND.rar  
Panasonic TX-L26X10E TNP8EA101.rar  
Panasonic TX-58AXW804 TNPH11002A 25Q64.rar  
Panasonic TX-55EX633E TNPH1179 LC550EQY 25L1606.rar  
Panasonic TX-50A400B TNP4G566 TXNA1ZXUB.rar  
Panasonic TX-42CSR610 TNP4G568 2A LC420DUJ-SGE3 24C16 MT29F4G08ABAEA NAND.rar  
Panasonic TX-42ASR600 TNP4G568 2A V420FWSD09 IC8901 24C16 IC8900 MT29F4G08ABAEAWP NAND.rar  
Panasonic TX-42ASE650 TNPH1077 1A LC420DUF-VGF1 24C16 .rar  
Panasonic TX-42AS520E KM26E TNP4G568 MT29F4G08ABAEAWP NAND.rar  
Panasonic TX-42AS500E TNP4G658-2A 24C16 MT29F4G08ABAEA NAND.rar  
Panasonic TX-42AR400 TNP4G566 A1 V420FWSD09 MX25L12835FM2I.rar  
Panasonic TX-42A400E\_TNP4G566 TXN-A1DYVE\_MX25L12835F.bin  
Panasonic TX-40DR400 TNPH1155 V400HJ9-MD1 REV.C2 24C16 TC58NYGOS3HTAIO NAND.rar  
Panasonic TX-40AS640E TNPH10771A 400UNDS-2E 24C16.rar  
Panasonic TX-39AW404 TNP4G566 A1 V390HJ1-LE6 REV.F1.rar  
Panasonic TX-37LZD80F TNPH0722 AX094F014A.rar  
Panasonic TX-32LZD85F TNPA44652DG.rar  
Panasonic TX-32LZD80F TNPH0722.rar  
Panasonic TX-32LXD80 TNP8EAL96 AX080A010B IC8401 24C16.rar  
Panasonic TX-32LX80M TNP4G431 AX080A010A 24C128.rar  
Panasonic TX-32LX70P TNPA41141DG IC8601 24C16.rar  
Panasonic TX-32LX60X TNPH0655 AG M25P10A.rar

Panasonic TX-32LX60PK TNP8EAL40 8AC LTA320W2-L13 24C32AN.rar  
Panasonic TX-32LE60P TNP8EAL40 T315XW02-V.2.rar  
Panasonic TX-32E3E TNP8EA114 VVX32F101G0 H27U1G8F2BTR NAND.rar  
Panasonic TX-32DSR500 TNP4G592 24C16 TC58NVG2S0HBA14 NAND.rar  
Panasonic TX-32DR400 TNP4G566 TZLP200KEAA3 25Q128.rar  
Panasonic TX-32CSR510 TNP4G568 3A 24C16 MT29F4G08ABAEA NAND.rar  
Panasonic TX-32CS510E TNP4G568 3 A LC320DXJ 24C16.rar  
Panasonic TX-32CR410 TNP4G566RL V320BJ7-PE1 rev.C1.rar  
Panasonic TX-32ASW504 TNPH1087 1A TPT315B5-DXJSFE 24C16 MT29F4G08ABAEA NAND.rar  
Panasonic TX-32ASR600 TNP10871A TPT315B5-DXJSFE 24C16RP.rar  
Panasonic TX-32AS520E TNPH1087 LC320DXE-SFR1 MT29F4G08ABAEA NAND.rar  
Panasonic TX-32AR300 TNP4G548 1A LC320DXJ-SFE1 MT29F1G08ABADA NAND.rar  
Panasonic TX-26LX60PK TNP8EAL40 LTA260W2-L09.rar  
Panasonic TX-26LX50P TNPA3488 2 DG LTA260W2-L05.rar  
Panasonic TX-26LE8PS TNPOEA012.rar  
Panasonic TX-26LE8FS TNPOEA012.rar  
Panasonic TX-26LE7F TNPOEA009 A9 LTA260W2-L12 24C32.rar  
Panasonic TX-26LE60PK TNP8EAL40 24C32.rar  
Panasonic TX-26LE60P TNP8EAL40A5 T260XW02.rar  
Panasonic TX-23LX50P TNP8EAL20 LTA230W1-L04.rar  
Panasonic TX20LB5P\_SL-115P.rar  
Panasonic TX-20LA2F TNP8EAL10 24C32.rar  
Panasonic TX-20AL2F\_ TNP8EAL10 LQ197V3DZ61 24C32.rar  
Panasonic TNPH1100 IC600 winbond 25q64fvsig\_ori.zip  
Panasonic TH-R50EL8K TNPH0711.rar  
Panasonic TH-R42PY8K TNPH0740 1A MC106F16T.rar

Panasonic TH-R42PY85A TNPH0763 MC106F16T11 S29GL256N9.rar  
Panasonic TH-R42PY85 TNPH0712.rar  
Panasonic TH-R42PV8KSA TNPH0711 MC106H30T11A 24LC16B.rar  
Panasonic TH-R42PV8A TNPH0711.rar  
Panasonic TH-R42PV7KH TNPA4414 S29GL128N90TFIR2.rar  
Panasonic TH-R42PV70K TNPA4414 MD-42GH10E1N.rar  
Panasonic TH-R42EL8KA TNPH0711.rar  
Panasonic TH-R42EL8K TNPH0711.rar  
Panasonic TH-R42EL7KS TNPA4414 24LC16.rar  
Panasonic TH-R37EL8KS TNPH0711.rar  
Panasonic TH-P50XT50C TNPH0990A MC127HY1511.rar  
Panasonic TH-P50X50P TNPH1002.rar  
Panasonic TH-P50X20M TNPH0842.rar  
Panasonic TH-P50U20C TNPH0840 MX25L1636D.rar  
Panasonic TH-P42XT50C TNPH0990CB MC106HY1511.rar  
Panasonic TH-P42X50M TNPH1002 W25Q16.rar  
Panasonic TH-P42X30M TNPH0961.rar  
Panasonic TH-P42X10S TNPH0783.rar  
Panasonic TH-L50B6M TNPA4G542.rar  
Panasonic TH-L42U30G TNP4G490.rar  
Panasonic TH-L39EM5E TNP4G529 V390HJ1-LE2 MX25L6405D.rar  
Panasonic TH-L39B6X TNP4G542 T390HVN02.3 25Q64.rar  
Panasonic TH-L39B6M TNP4G542 W25Q64.rar  
Panasonic TH-L37X10R TNP4G460(1)A LC370WXN-SBC1 24C16.rar  
Panasonic TH-L32XM6D TNP4G542 25Q64.rar  
Panasonic TH-L32XM5M TNP4G529 T320XVN01.1 25L6445E.rar

Panasonic TH-L32XM5E TNP4G529.rar  
Panasonic TH-L32XM5D TNP4G529 24C16.rar  
Panasonic TH-L32X20V TNP4G466 S29GL128N90TFIR2.rar  
Panasonic TH-L32SV6D TNP4G542 25Q64.rar  
Panasonic TH-L32EM5D TNP4G529.rar  
Panasonic TH-L32CH5 TNP4G506 L5EDDYY00344 MX25L6445E.rar  
Panasonic TH-L32C4V TNP4G506 25L64.rar  
Panasonic TH-L32C4M TNP4G506.rar  
Panasonic TH-L32C4G TNP4G506.rar  
Panasonic TH-L32C4D TNP4G506.rar  
Panasonic TH-L32C30R TNP4G487 24C16.rar  
Panasonic TH-L32C30M TNP4G4871A VVX32H100G00 H27U1G8F2BTR NAND.rar  
Panasonic TH-L32C30D TNP4G487 NAND.rar  
Panasonic TH-L32C22X TNP4G472 IC8004.rar  
Panasonic TH-L32C22D TNP4G472.rar  
Panasonic TH-L32C10X2 TNP4G460 A2.rar  
Panasonic TH-L32C10R2 TNP4G460 AX080A066G.rar  
Panasonic TH-L32C10M2 TNP4G460.rar  
Panasonic TH-L32B6X TNP4G548 LC320DXN W25Q64FV.rar  
Panasonic TH-L32B6M TNP4G542 W25Q64.rar  
Panasonic TH-L32B6D TNP4G542 W25Q64.rar  
Panasonic TH-L24XM6D TNP4G555.rar  
Panasonic TH-L24XM60D TNP4G555.rar  
Panasonic TH-L24C31D TNP4G506 MX25L6405.rar  
Panasonic TH-50AS610E TNP4G569.rar  
Panasonic TH-50A410D TNP4G564.rar

Panasonic TH-46PZ80EA TNPH07631A 24LC16B.rar  
Panasonic TH-42PZ85EA TNPH07121A.rar  
Panasonic TH-42PV600H TNPA3756 24C64.rar  
Panasonic TH-42PH30ER TNPH0924 MX29LV160DBTI-70G.rar  
Panasonic TH-42PA60R TNPA3756-1 MC106W36F9.rar  
Panasonic TH-42PA60C TNPA375 24C64.rar  
Panasonic TH-42PA30 TNPA3106.rar  
Panasonic TH-42PA20R TNPA2819 DG 24C32W.rar  
Panasonic TH-42C410D TNP4G565 W25Q64.rar  
Panasonic TH-42AM410D TNP4G564 W25Q64.rar  
Panasonic TH-42A410D TNP4G564 W25Q64.rar  
Panasonic TH-40C400S TNP4G565 MX25L12835F, 24C64RP V400HJ6-ME2 REV.C1.rar  
Panasonic TH-39A400X TNP4G564.rar  
Panasonic TH-37PV45EH TNPA3759.rar  
Panasonic TH-37PA60E TNPA3756 24C64.rar  
Panasonic TH-32U30D TNP4G490 24C16.rar  
Panasonic TH-32D450D TNP4G573.rar  
Panasonic TH-32C400D TNP4G573.rar  
Panasonic TH-32AM40E TNP4G573 V320BJ7-XCPE1 W25Q64.rar  
Panasonic TH-32A405D TNP4G573 V320BJ7-PE1 25Q64.rar  
Panasonic TH-32A400K TNP4G573 V320BJ7-PE1.rar  
Panasonic TH-32A300M TNP4G542.rar

**Panasonic Vestel**

**Panasonic TX-55CR430E 17MB100 citit tv palpaie ledul, nu a luat-o nici cu alte spi-uri.rar**

**Panasonic TX-55CR430B 17MB100.rar**

**Panasonic TX-50A300E 17MB95M VES500UNDC-2D-N01 U10 MX25L1606E.rar**

**Panasonic TX-50A300B 17MB95M VES500UNDC-2D-N01 MX25L1606E.rar**

**Panasonic TX-48CX400E 17MB100 VES480QNSS-3D-U01.rar**

**Panasonic TX-48CR300Z 17MB97 MX25L1606E MT29F2G08ABAEA NAND.rar**

**Panasonic TX-48C320 17MB97.rar**

**Panasonic TX-43GXW584 17MB130S VES430QNYL-2D 29F4G08ABAEA NAND.rar**

**Panasonic TX-43GX559ES 17MB130S VES430QNYL-2D-N02 NAND.rar**

**Panasonic TX-43FX550E 17MB130S VES430QNYL-2D-N01 U109 25L1606E.rar**

**Panasonic TX-43FS350 17MB211S MX25L1605 MT29F4G08ABAEA NAND.rar**

**Panasonic TX-43DS352E 17MB110P U81 25L1606.rar**

**Panasonic TX-43303E 17MB140 VES430UNDL U14 W25Q128.rar**

**Panasonic TX-40CXW404 17MB100 VES400QNSS-3D-U01.rar**

**Panasonic TX-40CXR400Z 17MB100 VES400UNDS-2D-N12.rar**

**Panasonic TX-40CW304 17MB97 VES400UNVS-2D-N02 U81 MX25L1605A.rar**

**Panasonic TX-40C320E 17MB97 U81 MX25L1606E.rar**

**Panasonic TX-40C300E 17MB97 VES400UNVS-2D-N03 25L1605.rar**

**Panasonic TX-40C200E 17MB82S VES400UNDS-2D-N11.rar**

**Panasonic TX-39EW334 17MB140 VES390UNDA-2D-N11 25L128.rar**

**Panasonic TX-39DW334 17MB110 25L1605D.rar**

**Panasonic TX-39DW304 17MB97 VES390UNDA-2D-N02 U81 25L160.rar**

**Panasonic TX-39AW304 17MB95M VES390UNDA MX25L1605D.rar**

**Panasonic TX-39A300E 17MB95S VES390UNDA-2D-N02 25L1606E.rar**

**Panasonic TX-39A300B 17MB95M MX25L1606E.rar**

Panasonic TX-39A3000E 17MB95M VES390UNDA-2D-N02 MX25L1606E.rar  
Panasonic TX-32GS350E 17MB211S VES315WNDS-2D-N22 25Q16.rar  
Panasonic TX-32FW334 17MB140 VES315WNDS-2D-N22 MX25L12835F.rar  
Panasonic TX-32E303E 17MB140 VES315WNDS-2D-N14 U14 MX25L12805.rar  
Panasonic TX-32E200E 17MB140 VES315WNDS-2D-N14 MX25L12805D.rar  
Panasonic TX-32CX300E 17MB97 25L1605.rar  
Panasonic TX-32CX300E 17MB70 LSC320AP01 MX25L1605D MT29F2G08ABAEA NAND.rar  
Panasonic TX-32C300E 17MB97 VES315WNDS-2D-N03 U81 25L1606E.rar  
Panasonic TX-32C200E 17MB82S VES315WNDS-01.rar  
Panasonic TX-32AW304 17MB95M VES315VESWNNDL-N01 MX25L1606E.rar  
Panasonic TX-32A300E 17MB95M VES315WNDL-N01 MX25L1606.rar  
Panasonic TX-24CW304 17MB97 VES236WNVC-2D-N01 25L1606E.rar  
Panasonic TX-24C300E 17MB97 VES236WNVC-2D-N01 U81 MX25L1606E.rar  
Panasonic TX-24C300B 17MB97 MX25L1605.rar  
17MB97\_VES390UNDA-2D-N02\_MX25L160\_Panasonic\_TX-39DW304.rar  
17MB95M\_VES500UNDC-2D-N01\_Panasonic\_TX-50A300E\_MX25L1605.rar  
17MB95M\_VES500UNDC-2D-N01\_MX25L1606E\_Panasonic\_TX-50A300E.rar  
17MB95M\_VES315WNDL-N01\_Panasonic\_TX-32A300E\_SPI\_Nand.rar  
17MB95M\_VES315WNDL-2D-N02\_Panasonic\_TX-32A300E\_U10\_MX25L1605.rar  
17MB95M\_VES315WNDL-2D-N02\_Panasonic\_TX-32A300E\_25Q16.rar  
17MB95\_Panasonic\_50A300.zip  
17MB82S\_Panasonic\_TX-32C200E\_VES315WNDS-2D-N11\_LSC320AP01-L04\_25Q16\_25Q64.rar  
17MB100\_VES480QNSS-3D-U01\_Panasonic\_TX-48CX400E\_MX25L1605\_U26\_U27\_25Q32.zip  
17MB100\_V1.33.11\_Core\_Panasonic.zip

**Megapack soft 2024 - Volum I = Hisense RSAG7 - EMMC - 114 softuri eMMC**

**Part 1**

**RSAG7.820.6591\_Noblex EA50X6500 EMMC AUTO ISP 2701 = Sharp SH5016KUHD.rar**

**RSAG7.820.6591 EMMC\_AUTO\_ISP\_2521 Noblex EA65X6500.rar**

**RSAG7.820.6591 Dexp U40B9000H H26M3001HPR EMMC.rar**

**RSAG7.820.6526 Hisense 55K3140PW EMMC.rar**

**RSAG7.820.6510 EMMC Hisense LED50K3100A.rar**

**RSAG7.820.6487\_HE480HF-B31\_EMMC.rar**

**RSAG7.820.6487\_EMMC\_Panel-HE400HF-E31.txt**

**RSAG7.820.6487\_EMMC\_Panel-HE400HF-E31.rar**

**RSAG7.820.6487 EMMC\_6487\_50FHD\_G0606 JVC LT-50DA965.rar**

**RSAG7.820.6487 EMMC\_43K352WAM\_G0229 JVC LT-43DA760.rar**

**RSAG7.820.6450 H26M31001HPR EMMC Hisense LTDN43K351WT.rar**

**RSAG7.820.6312 EMMC Hisense LED50MU8600UC.rar**

**RSAG7.820.6299 EMMC Hisense LED50EC520UA.rar**

**RSAG7.820.6270 H26M41103HPR EMMC Hisense LED50X1A.rar**

**RSAG7.820.6261 V580DJ2-KS5 EMMC Dexp U58B9900H.rar**

**RSAG7.820.6135 Dexp U40B9000H EMMC.rar**

**RSAG7.820.6041 EMMC Hisense LED55K380U.rar**

**RSAG7.820.6040 HD550DF-B32 EMMC Hisense LED55EC290N.rar**

**RSAG7.820.6040 EMMC Hisense LED50K220.rar**

**RSAG7.820.6016 HD500DU-B01S EMMC Hisense LED50K320U.rar**

**RSAG7.820.6006 EMMC Hisense LED32K220.rar**

**RSAG7.820.5972 T420HVN06 EMMC Hisense LED42K220.rar**

**RSAG7.820.5785 HE315GH-B12 EMMC Hisense LED32L288.rar**

**RSAG7.820.5773 EMMC Hisense LED40K370.rar**

RSAG7.820.5730 EMMC Hisense 50K380U.rar  
RSAG7.820.5583 MT5327AEDJ EMMC Hisense LED60K380(BOM3).rar  
RSAG7.820.5277 HD550DF-B51 EMMC Hisense LED55K20JD.rar  
RSAG7.820.5277 EMMC Hisense LED58K280J.rar  
RSAG7.820.5060 HE550HFD-B31 EMMC Hisense LED55630JD.rar  
RSAG7.820.5060 EMMC Hisense LED55K360X3D.rar

Part 2

RSAG7.820.7412 HD490N3U82 EMMC Dexp U49D9000H.rar  
RSAG7.820.7237 EMMC Hisense LED43EC520UA.rar  
RSAG7.820.6983 EMMC\_AUTO\_ISP\_20171122\_200822 JVC LT-50DA770.rar  
RSAG7.820.6954 Hisense 40K3110PW EMMC.rar  
RSAG7.820.6935 EMMC Hisense LED55EC780UC.rar  
RSAG7.820.6854 HD550DU-E31 EMMC Hisense LED55K300UD.rar  
RSAG7.820.6854 EMMC Hisense LED55EC520UA.rar  
RSAG7.820.6823 EMMC-6823\_32HD\_G1103\_NewWiFi Philco PLD3226HIX.rar  
RSAG7.820.6823 EMMC\_AUTO\_ISP\_20171128\_140154 Philco PLD4326FIX.rar  
RSAG7.820.6823 EMMC\_AUTO\_ISP\_20171120\_173236 JVC LT-32DA770.rar  
RSAG7.820.6823 EMMC\_6823\_40FHD\_G0918 JVC LT-40DA770.rar  
RSAG7.820.6815 JHD490DF-B71 EMMC Hisense H49M2600.rar  
RSAG7.820.6772 EMMC Hisense LED65MU7000U.rar  
RSAG7.820.6738 EMMC Hisense LED43K3100.rar  
RSAG7.820.6715 Hisense H49N6600 HE490C5U3P-B1 N56 KLM8G1GEME-B041 EMMC.rar  
RSAG7.820.6688 EMMC Hisense LED32H1600Y.rar  
RSAG7.820.6674 EMMC Hisense LED49H1600Y.rar  
RSAG7.820.6592 EMMC Hisense LED32EC320A MT5507AEHJ.rar

Part 3

RSAG7.820.7800 HV320WHB-N86 EMMC Hisense HZ32E35A.rar  
RSAG7.820.7700 EMMC Hisense LED55NU7700U.rar  
RSAG7.820.7683 EMMC Hisense 88L6.rar  
RSAG7.820.7667 EMMC Hisense LED55N3600U.rar  
RSAG7.820.7655 HD500K3U54KLM4G1FEPD EMMC Hisense H50N5300.rar  
RSAG7.820.7557 EMMC Hisense 55EC500U.rar  
RSAG7.820.7532 EMMC Hisense LED50N3700U.rar  
RSAG7.820.7520 EMMC Hisense LED55N39U.rar

Part 4

RSAG7.820.7969 Hisense H65U7A HE650S5U52-B1 N56 KLM4G1FEPD-B031 EMMC.rar  
RSAG7.820.7949 EMMC Hisense HZ55A66.rar  
RSAG7.820.7924 JHD315S1H71-T0 THGBMBG5D1KBAIL EMMC Toshiba 32L5865.rar  
RSAG7.820.7921 EMMC Hisense H65A6100.rar  
RSAG7.820.7918 Dexp U55D9000H EMMC.rar  
RSAG7.820.7901 T430HVN01.2 EMMC HZ43E35A.rar  
RSAG7.820.7825 ST5461D07 EMMC Hisense HZ55A65.rar

Part 5

RSAG7.820.8622 HV430FHBN10 EMMC Hisense HZ43E35A.rar  
RSAG7.820.8609 T430HVN01.1 EMMC Dexp F43E8000H.rar  
RSAG7.820.8502 Hisense HZ32E35A.rar  
RSAG7.820.8281 MSD6A648WY-8-00B2 EMMC Hisense H50E3A.rar  
RSAG7.820.8281 EMMC Hisense H58E3A MSD6A648WY.rar  
RSAG7.820.8280 EMMC Hisense HZ43E35A.rar  
RSAG7.820.8063 Hisense 49A5700PW KLM4G1FEPD-B031 EMMC.rar  
RSAG7.820.8052 EMMC Hisense HZ55A51 HD550S1U81S1.rar  
RSAG7.820.8002 EMMC Hisense HZ50A55.rar

**Part 6**

RSAG7.820.9180 EMMC Hisense HZ65A55E.rar  
RSAG7.820.9018 KLM4G1FETE B041 EMMC Hisense HZ40E35D.rar  
RSAG7.820.8959 HD315S1H81-T0 EMMC Hisense HZ32E35A.rar  
RSAG7.820.8869 JHD396V1F01-TXL1 KLM4G1FETE-B041 EMMC Hisense H40B5600.rar  
RSAG7.820.8831 HD650V1U72-T0L1 N70 THGBMNG5D1LBAIL EMMC Dexp U65E9000H.rar  
RSAG7.820.8803 EMMC Hisense HZ65A55.rar  
RSAG7.820.8802 EMMC Hisense HZ55A52.rar  
RSAG7.820.8796 EMMC Hisense 55A65F.rar  
RSAG7.820.8768 EMMC Hisense HZ50A55.rar

**Part 7**

RSAG7.820.9399 HD550X1U51-T0 EMMC Hisense HZ50E3D 55V1F.rar  
RSAG7.820.9380 EMMC Hisense HZ55E3D.rar  
RSAG7.820.9373 H26M41204HPR EMMC Hisense HZ58E3D.rar  
RSAG7.820.9252 H26M41204HPR EMMC Hisense H55E3A.rar

**Part 8**

RSAG7.820.9663 ST5461D13-2 Ver.2.2 THGBMNG5D1LBAIL EMMC Dexp U55F8000H.rar  
RSAG7.820.9662 EMMC Hisense 43A7300F.rar  
RSAG7.820.9615 EMMC Hisense 55E3A.rar  
RSAG7.820.9614 EMMC Hisense 43V1F-R.rar  
RSAG7.820.9580 JHD550X3U81-TAL2K2 EMMC Hisense 55AE7400F.rar  
RSAG7.820.9538 EMMC Hisense H65E3A.rar  
RSAG7.820.9505 EMMC Hisense HZ43E3D.rar  
RSAG7.820.9502 HD500X1U91-L1 N70 THGBMNG5D1LBAIL EMMC Toshiba 50U5069.rar  
RSAG7.820.9484 MT9632EAATAB 8G EMMC Hisense HZ65A55E.rar  
RSAG7.820.9467 8G EMMC Hisense H50E3A.rar

RSAG7.820.9428 HD500X1U51 EMMC Hisense 50A52E.rar

Part 9

RSAG7.820.9845 EMMC Hisense 32A5600.rar

RSAG7.820.9664 EMMC Hisense 43A37F(BOM2).rar

RSAG7.820.10716 HD500Y1U51-TOL2 KLM4G1FETE EMMC Hisense 50A6G.rar

RSAG7.820.10611 HD650YU41-B1 MT9632 16G V5.1 EMMC Hisense 65A5F-SE.rar

RSAG7.820.10510 EMMC Hisense 55A52F.rar

RSAG7.820.10004 EMMC Hisense 32E2F-PRO.rar

Part 10

RSAG7.820.9850 HD550V1U72 EMMC Hisense H55E3A.rar

RSAG7.820.9250 EMMC Hisense HZ55A52.rar

RSAG7.820.8752 THGBMBG5D1KBAIL EMMC Dexp U43D9100H.rar

RSAG7.820.8751 HD550V1U51-TOL4 EMMC Dexp U55E9000H.rar

RSAG7.820.8698 HD500V3U51-TAL2 EMMC Hisense H50B7500.rar

RSAG7.820.8625 EMMC Hisense 43H35A.rar

RSAG7.820.12367 PT320AT-C-1 EMMC Hisense 32A4BG.rar

RSAG7.820.12085 EMMC Hisense 75E3F.rar

RSAG7.820.11620 CCPD-XL575-003 V2.0 EMMC Hisense 58A6BG.rar

RSAG7.820.11566 T430HVN01.3 EMMC Hisense 43A4G.rar

RSAG7.820.11033 NT72691TBG-C EMMC Vidda 55V1F-S.rar

RSAG7.820.10830 EMMC Hisense 55E3F.rar

Megapack soft 2024 - Volum I = MONITOARE - NVM FLASH USB

779 fisiere - softuri USB , softuri Flash , softuri NVM , poze cu placile de baza

ACER\ LG\ MIX MONITOR\ AOC\ AOC USB\ ASUS\ PHILIPS\ BENQ\ SAMSUNG\ DELL\ VIEWSONIC\ HP\ 
--